
You can add extra leaders to existing notes by placing another note leader without any text, but how do you make it associated so that if the note is moved all leaders adjust to the new text location.


Here is the simple solution, but there are a couple of things to have set for it to be able to happen.

- 1. The existing Note must have been placed with these settings.
 - Association Lock must be
 ON, if it is disabled (greyed out) turn the Association
 Lock on in the Locks options.




b. In older versions of MicroStation the In-Line Leader must also be ON





Existing Note



- 3. Modify the text end of the new leaders with the Modify Element tool or just use the handles to attach the ends to the existing leader.
 - a. In older versions of MicroStation the new leader must be snapped to the In-Line leader, not the leader line.
- 4. Now when you move the Note, the leaders automatically adjust.

